

Glass Skin Cica Repair Serum

ID	FACE Care / FO0055
pH-value	5.2 - 5.4
Appearance	Transparent, light-pink serum
Product Form	Gel
Claims	Regenerating

St	Substance	INCI Name USA	% w/w	Manufacturer
1	Water demin	Water	81.35	Several
	Dermosoft Pentiol eco	Pentylene Glycol	3.00	Evonik, DE
	Suncroma FD&C Red No. 40 solution 1.0%	Water, FD&C Red No. 40	0.05	Sun Chemical, US
2	Glycerin 99.5%	Glycerin	5.00	Several
	Genuvisco CG-129	Carrageenan	2.00	Tate & Lyle, US
	TN001CR Aloe Vera Powder 200x	Aloe Barbadensis Leaf Juice Powder	0.05	Terry, US
3	Centella-P PDRN 100	Water, 1,2-Hexanediol, Sodium DNA	1.00	BIO-FD&C, KR
	Prodew 600	Betaine, Sodium PCA, Sodium Lactate, PCA, Serine, Alanine, Glycine, Glutamic Acid, Lysine HCL, Threonine, Arginine, Proline, Water	1.00	Ajinomoto, JP
4	Tego Solve 90 MB	Polyglyceryl-6 Caprylate, Polyglyceryl-4 Caprate	2.00	Evonik, DE
	Moringa Power	Fragrance	0.05	Bell Flavors & Fragrances, DE
5	Dermosoft 1388 ECO	Glycerin, Water, Sodium Levulinate, Sodium Anisate	4.00	Evonik, DE
	Citric Acid solution 10%	Citric Acid, Water	0.50	Several

Production

Combine ingredients of phase 1 / Premix Genuvisco CG-129 in Glycerin and add premix to phase 1 with homogenizer / Add ingredients of 3 with propeller mixing / Premix fragrance in Tego Solve 90 MB and add premix to the main batch / Add ingredients of 5 in given order with mixing.

Stability: Stable for more than 3 months at 5°, 25° and 40°C

Disclaimer

Utilisation of this document or parts thereof as well as product names for commercial or industrial applications is subject to explicit written approval by RAHN AG. This information is based on our own experience to date and we believe it to be reliable. It is intended only as a guide to use at your discretion and risk. We cannot guarantee favourable results and we assume no liability in connection with its use, or the use of the methods or products described. None of this information is to be taken as a license to operate under, or a recommendation to infringe, patents.

Version: 10/2025

Glass Skin Cica Repair Serum

Microbiological Stability: ---

Disclaimer

Utilisation of this document or parts thereof as well as product names for commercial or industrial applications is subject to explicit written approval by RAHN AG. This information is based on our own experience to date and we believe it to be reliable. It is intended only as a guide to use at your discretion and risk. We cannot guarantee favourable results and we assume no liability in connection with its use, or the use of the methods or products described. None of this information is to be taken as a license to operate under, or a recommendation to infringe, patents.

Version: 10/2025